

CE

Model Number

OBE2000-R2-SE2

Thru-beam sensor with 2 m fixed cable

Features

- Ultra-small housing design •
- 45° cable outlet for maximum mounting freedom under extremely tight space constraints
- Improvement in machine availability • with abrasion-resistant, antistatic glass front
- Extremely large detection range in ٠ Long Range Mode
- Option of switching to high precision mode for greater switching accuracy

Product information

The R2 series nano sensor has been developed for a broad range of applications. It offers excellent durability and is exceptionally easy to install. The housing is compact and, with its 45° cable outlet, can be installed in the smallest spaces. New functional principles and functionality open up a range of new options. The abrasion-resistant lens allows long operating times close to the moving object.

Dimensions



Electrical connection



$$\mathbf{O} = \text{Light on}$$

Indicators/operating means



Pepperl+Fuchs Group

www.pepperl-fuchs.com

Refer to "General Notes Relating to Pepperl+Fuchs Product Information"

USA: +1 330 486 0001 fa-info@us.pepperl-fuchs.com

Germany: +49 621 776 4411 fa-info@de.pepperl-fuchs.com

Singapore: +65 6779 9091 fa-info@sg.pepperl-fuchs.com



1

Technical data	
System components	
Emitter	OBE2000-R2
Receiver	OBE2000-R2-E2
General specifications	
Effective detection range	Long range mode: 0 2 m
	High precision mode: 0 200 mm
Threshold detection range	Long range mode: 2.5 m High precision mode: 300 mm
Light source	LED
Light type	modulated visible red light , 630 nm
Angle deviation	approx. 2 °
Diameter of the light spot	Long range mode: 150 mm at a distance of 2000 mm High preci sion mode: 0.5 mm at a distance of 50 mm approx. 2 °
Angle of divergence	frontal
Optical face Ambient light limit	EN 60947-5-2 : 30000 Lux
Functional safety related parameter	
MTTF _d	806 a
Mission Time (T _M)	20 a
Diagnostic Coverage (DC)	0 %
ndicators/operating means	· · · ·
Operating display	LED green, statically lit Power on , short-circuit : LED green flas-
Function display	hing (approx. 4 Hz) Receiver: LED yellow, lights up when light beam is free, flashes
	when falling short of the stability control ; OFF when light beam is interrupted
lectrical specifications	
Operating voltage U	3 10 30 V DC , class 2
No-load supply current I ₀	Emitter: ≤ 11 mA Receiver: ≤ 8 mA
nput	
Control input	Emitter selection BK: not connected, Long Range mode BK: 0 V, High Precicion Mode
Switching threshold	TEACH-IN input
Dutput	
Switching type	NO contact
Signal output	1 PNP output, short-circuit protected, reverse polarity protected, open collector
Switching voltage	max. 30 V DC
Switching current	max. 50 mA
Voltage drop U	•
Switching frequency f	approx. 800 Hz
Response time	600 μs
Ambient conditions	
Ambient temperature	-25 60 °C (-13 140 °F)
Storage temperature	-30 70 °C (-22 158 °F)
Nechanical specifications	IDC7
Protection degree	IP67 2 m fixed cable
Connection Material	
Housing	PC/ABS and PBT
Optical face	glass
Cable	PUR
Installation	Fixing screws , 2 x M2 allen head screws included with delivery
Mass	approx. 20 g Per sensor
Compliance with standards and dir	
Directive conformity	
EMC Directive 2004/108/EC	EN 60947-5-2:2007
Approvals and certificates	
UL approval	cULus Recognized, Class 2 Power Source
CCC approval	CCC approval / marking not required for products rated ≤36 V

Accessories

MH-R2-01 Mounting bracket

MH-R2-02 Mounting bracket

MH-R2-03 Mounting bracket

MH-R2-04 Mounting bracket

Other suitable accessories can be found at www.pepperl-fuchs.com

Germany: +49 621 776 4411 fa-info@de.pepperl-fuchs.com



2

Curves/Diagrams







Release date: 2013-05-03 14:13 Date of issue: 2013-05-03 225909_eng.xml

Refer to "General Notes Relating to Pepperl+Fuchs Product Information" Pepperl+Fuchs Group USA: +1 330 486 0001

www.pepperl-fuchs.com fa-info@us.pepperl-fuchs.com

Germany: +49 621 776 4411 fa-info@de.pepperl-fuchs.com

Singapore: +65 6779 9091 fa-info@sg.pepperl-fuchs.com









Teach-In Methods

The thru-beam sensor enables the switching points to be taught in for optimum adaptation to specific applications. This eliminates the need for additional components such as apertures.

Essentially, all Teach-in methods can be used in both "High Precision" and "High Power" operating modes.

The sensitivity of the thru-beam sensor can be adjusted using three Teach-in methods:

Position Teach

When using this Teach-in method, the following settings are made on the thru-beam sensor:

· The gain is set to an optimum value

• The signal threshold is set to a minimum

Date of issue: 2013-05-03 225909_eng.xml Release date: 2013-05-03 14:13

Germany: +49 621 776 4411 fa-info@de.pepperl-fuchs.com

Singapore: +65 6779 9 fa-info@sg.pepperl-fuchs.c

4



Recommended application:

This method enables extremely small differences in contrast to be detected, as well as minuscule particles in the beam path, and provides exceptional positioning accuracy.

The best results are achieved in "High Precision" mode.

- 1. Make sure that there are no objects in the beam path and that the sensor is connected to the power supply.
- 2. Connect the white cable on the receiver (WH/IN) to the blue cable (BU/0 V) on the receiver.
- The green and yellow LED indicators flash simultaneously at 2.5 Hz
- 3. Disconnect the white cable on the receiver (WH/IN) from the blue cable (BU/0 V) on the receiver. The green and yellow LED indicators flash alternately at 2.5 Hz
- 4. The end of the Teach-in process is indicated when the green LED indicator lights up sold and yellow LED blinks.

Two-Point Teach-In

When using this Teach-in method, the following settings are made on the thru-beam sensor:

- · The gain is set to an optimum value
- · The signal threshold is set in the center between the two taught signal values

Signal	strength		
Max			
	Teach-in value 1 (avg) Threshold level	> Contrast levels	
	Teach-in value 2 (avg)		
0 -		t t	

Recommended application:

Enables detection of transparent objects.

The best results are achieved in "High Precision" mode.

- 1. Make sure that there are no objects in the beam path and that the sensor is connected to the power supply.
- 2. Connect the white cable on the receiver (WH/IN) to the blue cable (BU/0 V) on the receiver. The green and yellow LED indicators flash simultaneously at 2.5 Hz
- 3. Position the object in the beam path.
- 4. Disconnect the white cable on the receiver (WH/IN) from the blue cable (BU/0 V) on the receiver. The green and yellow LED indicators flash alternately at 2.5 Hz
- 5. The end of the Teach-in process is indicated when the green LED indicator lights up sold.

Maximum Teach-In

- When using this Teach-in method, the following settings are made on the thru-beam sensor:
- · The gain is set to a maximum
- · The signal threshold is set to a minimum

Signal strength		-	
Max			
			1
	Threshold level		
0			_



Recommended application:

Enables an object to be detected with a high excess gain. This can be useful if there is severe environmental contamination or to achieve long operating times.

The best results are achieved in "High Precision" mode.

- 1. Make sure that there are no objects in the beam path and that the sensor is connected to the power supply.
- 2. Cover the receiver or transmitter.
- 3. Connect the white cable on the receiver (WH/IN) to the blue cable (BU/0 V) on the receiver. The green and yellow LED indicators flash simultaneously at 2.5 Hz
- 4 Disconnect the white cable on the receiver (WH/IN) from the blue cable (BU/0 V) on the receiver. The green and yellow LED indicators flash alternately at 2.5 Hz
- 5. The end of the Teach-in process is indicated when the green LED indicator lights up sold.

Germany: +49 621 776 4411 fa-info@de.pepperl-fuchs.com

