
# **CE** 0102 FM APPROVED **Model Number**

- 8 mm non-flush
- Usable up to SIL2 acc. to IEC 61508





Ac	ce	SS	ori	ies
70	UC	00	011	

BF 18 Mounting flange, 18 mm



#### App

FM approval	
Control drawing	116-0165F
UL approval	cULus Listed, General Purpose
CSA approval	cCSAus Listed, General Purpose
CCC approval	CCC approval / marking not required for

Refer to "General Notes Relating to Pepperl+Fuchs Product Information"

Pepperl+Fuchs Group www.pepperl-fuchs.com

USA: +1 330 486 0001 fa-info@us.pepperl-fuchs.com

Germany: +49 621 776 4411 fa-info@de.pepperl-fuchs.com

Singapore: +65 6779 9091 fa-info@sg.pepperl-fuchs.com



M18x1 16

**Technical Data** 

**Dimensions** 

reonnoar Data			
General specifications			
Switching element function		NAMUR, NC	
Rated operating distance	s <sub>n</sub>	8 mm	
Installation		non-flush	
Output polarity		NAMUR	
Assured operating distance	sa	0 6.48 mm	
Reduction factor r <sub>Al</sub>		0.4	
Reduction factor r <sub>Cu</sub>		0.3	
Reduction factor r <sub>304</sub> Nominal ratings		0.85	
U U		0.01/(P	
Nominal voltage	Uo	8.2 V ( $R_i$ approx. 1 k $\Omega$ )	
Operating voltage	U <sub>B</sub>	5 25 V 0 200 Hz	
Switching frequency Hysteresis	I H	3 %	
Current consumption	п	5 /8	
Measuring plate not detected		> 3 mA	
Measuring plate detected		<1 mA	
Ambient conditions		21100	
Ambient temperature		-25 100 °C (-13 212 °F)	
Mechanical specifications		-25 100 C (-13 212 F)	
•			
Connection type Core cross-section		cable PVC , 2 m 0.75 mm <sup>2</sup>	
		Stainless steel 1.4305 / AISI 303	
Housing material Sensing face		PBT	
Protection degree		IP67	
General information			
Use in the hazardous area		see instruction manuals	
Category		1G; 2G; 1D	
Compliance with standards and di	rective	· · ·	
•	COLIVE.	5	
Standard conformity			
NAMUR		EN 60947-5-6:2000	
		IEC 60947-5-6:1999	
Standards		EN 60947-5-2:2007	
		IEC 60947-5-2:2007	
Approvals and certificates			
FM approval			
Control drawing		116-0165F	
UL approval		cULus Listed, General Purpose	
CSA approval		cCSAus Listed, General Purpose	
CCC approval		CCC approval / marking not required for products rated ≤36 V	

ATEX 1G	
Instruction	Manual electrical apparatus for hazardous areas
Device category 1G	for use in hazardous areas with gas, vapour and mist
EC-Type Examination Certificate	PTB 00 ATEX 2048 X
CE marking	€ € 0102
ATEX marking	⟨٤͡∞⟩ II 1G Ex ia IIC T6 Ga
Directive conformity	94/9/EG
Standards	EN 60079-0:2009, EN 60079-11:2007, EN 60079-26:2007 Ignition protection "Intrinsic safety" Use is restricted to the following stated conditions
Appropriate type	NJ 8-18GM-N
Effective internal capacitance C <sub>i</sub>	$\leq$ 70 nF ; a cable length of 10 m is considered.
Effective internal inductance Li	$\leq$ 50 $\mu H$ ; a cable length of 10 m is considered.
Cable length	Dangerous electrostatic charges on the fixed connection cable must be taken into account for lengths equal to and exceeding the following values:
Explosion group IIA	78 cm
Explosion group IIB	39 cm
Explosion group IIC	6 cm
General	The apparatus has to be operated according to the appropriate data in the data sheet and in this instruction manual. The EC-Type Examination Certificate has to be observed. The special conditions must be adhered to! Directive 94/9/EG and hence also EC-Type Examination Certificates apply in general only to the use of electrical apparatus under atmospheric conditions. The use in ambient temperatures of > 60 °C was tested with regard to hot surfaces by the mentioned certification authority. If the equipment is not used under atmospheric conditions, a reduction of the permissible minimum ignition energies may have to be taken into consideration.
Ambient temperature	The temperature ranges, according to temperature class, are given in the EC-Type Examination Certificate. Note: Use the temperature table for category 1 !!! The 20 % reduction in accordance with EN 1127-1:2007 has already been accounted for in the temperature table for category 1.
Installation, Comissioning	Laws and/or regulations and standards governing the use or intended usage goal must be observed. The intrinsic safety is only assured in connection with an appropriate related apparatus and according to the proof of intrinsic safety. The associated apparatus must satisfy the requirements of category ia. Due to the possible danger of ignition, which can arise due to faults and/or transient currents in the equipotential bonding system, galvanic isolation of the power supply and signal circuit is preferable. Associated apparatus without electrical isolation must only be used if the appropriate requirements of IEC 60079-14 are met.
Maintenance	No changes can be made to apparatus, which are operated in hazardous areas. Repairs to these apparatus are not possible.
Specific conditions	
Protection from mechanical danger	When used in the temperature range below -20 °C the sensor should be protected from knocks by the provision of an additional housing.
Electrostatic charging	Electrostatic charges on the metal housing components must be avoided. Dange- rous electrostatic charges on the metal housing components can be avoided by incorporating these components in the equipotential bonding.

Release date: 2013-06-26 09:54 Date of issue: 2013-06-26 106470\_eng.xml

2

Germany: +49 621 776 4411 fa-info@de.pepperl-fuchs.com



#### ATEX 2G

Instruction

Device category 2G EC-Type Examination Certificate CE marking

ATEX marking

Directive conformity Standards

#### Appropriate type

Effective internal capacitance C<sub>i</sub> Effective internal inductance L<sub>i</sub> General

Ambient temperature

Installation, Comissioning

Maintenance

#### Specific conditions Protection from mechanical danger

Electrostatic charging

Manual electrical apparatus for hazardous areas

for use in hazardous areas with gas, vapour and mist PTB 00 ATEX 2048 X CE0102

🐼 II 1G Ex ia IIC T6 Ga

94/9/EG EN 60079-0:2009, EN 60079-11:2007 Ignition protection "Intrinsic safety" Use is restricted to the following stated conditions

### NJ 8-18GM-N...

 $\leq$  70 nF ; a cable length of 10 m is considered.

 $\leq$  50  $\mu$ H ; a cable length of 10 m is considered.

The apparatus has to be operated according to the appropriate data in the data sheet and in this instruction manual. The EC-Type Examination Certificate has to be observed. The special conditions must be adhered to!

Directive 94/9/EG and hence also EC-Type Examination Certificates apply in general only to the use of electrical apparatus under atmospheric conditions. The use in ambient temperatures of > 60 °C was tested with regard to hot surfaces

by the mentioned certification authority.

If the equipment is not used under atmospheric conditions, a reduction of the permissible minimum ignition energies may have to be taken into consideration.

The temperature ranges, according to temperature class, are given in the EC-Type Examination Certificate.

Laws and/or regulations and standards governing the use or intended usage goal must be observed. The intrinsic safety is only assured in connection with an appropriate related apparatus and according to the proof of intrinsic safety.

No changes can be made to apparatus, which are operated in hazardous areas. Repairs to these apparatus are not possible.

When used in the temperature range below -20  $^{\circ}\text{C}$  the sensor should be protected from knocks by the provision of an additional housing.

Electrostatic charges must be avoided on the mechanical housing components. Dangerous electrostatic charges on the mechanical housing components can be avoided by incorporating these in the equipotential bonding.

Pepperl+Fuchs Group www.pepperl-fuchs.com USA: +1 330 486 0001 fa-info@us.pepperl-fuchs.com Germany: +49 621 776 4411 fa-info@de.pepperl-fuchs.com

Singapore: +65 6779 9091 n fa-info@sg.pepperl-fuchs.com



## ATEX 1D

Instruction

Device category 1D EC-Type Examination Certificate CE marking

ATEX marking Directive conformity Standards

Appropriate type Effective internal capacitance C<sub>i</sub> Effective internal inductance Li General

Maximum housing surface temperature

Installation, Comissioning

Maintenance

Specific conditions

Electrostatic charging

Manual electrical apparatus for hazardous areas

for use in hazardous areas with combustible dust ZELM 03 ATEX 0128 X €0102

(Ex) II 1D Ex iaD 20 T 108 °C (226.4 °F) 94/9/EG IEC 61241-11:2002: draft; prEN61241-0:2002 type of protection intrinsic safety "iD" Use is restricted to the following stated conditions

NJ 8-18GM-N...

 $\leq$  70 nF ; a cable length of 10 m is considered.  $\leq$  50  $\mu H$  ; a cable length of 10 m is considered.

The apparatus has to be operated according to the appropriate data in the data sheet and in this instruction manual.

The EC-Type Examination Certificate has to be observed.

The special conditions must be adhered to!

The maximum surface temperature of the housing is given in the EC-Type Examination Certificate.

NJ8-18GM-N

Laws and/or regulations and standards governing the use or intended usage goal must be observed

The intrinsic safety is only assured in connection with an appropriate related apparatus and according to the proof of intrinsic safety.

The associated apparatus must satisfy at least the requirements of category ia IIB or iaD. Because of the possibility of the danger of ignition, which can arise due to faults and/or transient currents in the equipotential bonding system, galvanic isolation in the power supply and signal circuits is preferable. Associated apparatus without electrical isolation must only be used if the appropriate requirements of IEC 60079-14 are met.

The intrinsically safe circuit has to be protected against influences due to lightning. When used in the isolating wall between Zone 20 and Zone 21 or Zone 21 und Zone 22 the sensor must not be exposed to any mechanical danger and must be sealed in such a way, that the protective function of the isolating wall is not impaired. The applicable directives and standards must be observed.

No changes can be made to apparatus, which are operated in hazardous areas. Repairs to these apparatus are not possible.

Electrostatic charges must be avoided on the mechanical housing components. Dangerous electrostatic charges on the mechanical housing components can be avoided by incorporating these in the equipotential bonding. The connection cables are to be laid in accordance with EN 50281-1-2 and must not normally be subjected to chaffing during use.

w.pepperl-fuchs.com

Singapore: +65 6779 9091 fa-info@sg.pepperl-fuchs.

