## **Features**

- 2-channel
- AC version
- Working voltage 26 V at 10 μA
- Series resistance max. 646  $\Omega$
- Fuse rating 50 mA
- · DIN rail mounting
- · Star connection


## **Function**

The Zener Barrier prevents the transfer of unacceptably high energy from the safe area into the hazardous area.

The zener diodes in the Zener Barrier are connected in the reverse direction. The breakdown voltage of the diodes is not exceeded in normal operation. If this voltage is exceeded, due to a fault in the safe area, the diodes start to conduct, causing the fuse to blow. The Zener Barrier has alternating polarities, i. e. interconnected zener diodes are employed and one side is grounded. The Zener Barrier can be used for both alternating voltage signals and direct voltage signals.


Depending on the application, increased or decreased intrinsic safety parameters apply for serial or parallel connection. For the detailed parameters refer to the Zener Barrier certificate. Application examples can be found in the system description of the Zener Barriers.


## **Assembly**





## Connection





Zone 2 Div. 2

Refer to "General Notes Relating to Pepperl+Fuchs Product Information".

Release date 2020-01-08 08:51 Date of issue 2020-01-08 071862\_eng.xml

**General specifications** 

**Electrical specifications** Nominal resistance

Hazardous area connection

Safe area connection

Measurement loop

**Ambient conditions** 

Series resistance

Fuse rating

Connection

Connection

Conformity Degree of protection

Working voltage Supply loop

Type

AC version

max. 646  $\Omega$ 50 mA

terminals 1, 2; 3, 4

terminals 5, 6; 7, 8

 $\leq$  26 V at 10  $\mu$ A

 $\leq$  26.3 V

IEC 60529

 $600 \Omega$